

Mark Crispin  
SU-AI  
31 October 1977

1. Command name and code.

## 2. Command meanings.

IAC WON'T SUPDUP

IAC DO SUPDUP

The sender of this command REQUESTS that the receiver use, or grants the receiver permission to use, the SUPDUP protocol.

IAC DON'T

The sender of this command DEMANDS that the receiver not use the SUPDUP protocol.

3. Default.

WON'T SUPDUP

DON'T SUPDUP

i.e., the SUPDUP display protocol is not in use.



[illegible]